

Ref.	Description	Position	Ref.	Description	Position
1	Headlamp, front, right-hand : - Main beam - Dipped beam - Sidelamp	22 20 18	14 15 16 17 18	Windscreen wiper switch Switch for parking lamps Speedometer light Charge warning lamp Fuel gauge	13 10-11 16 5 7
2	Ignition coil	6	19	Switch for lighting and horn	9-11
3	Headlamp, front, left-hand : - Main beam	21	20	Interior lamps (AZAW and AZU)	15
	- Dipped beam	17	21	Fuel gauge rheostat	7
	- Sidelamp	19	22	Lamp for direction indicator and parking, R.H	9-11
4	Distributor	6	23	Lamp for direction indicator and parking, L.H	8-10
5	Dynamo	3 - 4	24	Rear, side and stop lamp R.H (AZAW)	16-13
6	Starter	2	25	Number plate lamp, rear (AZL - AZA - AZAW → 3 / 1964)	15
7	Horn (Town and country)	22-23		Rear, side and stop lamp, L.H	14-12
8	Regulator	3 - 4	26	Flasher unit (AZAW) see ref. 13	8
9	Battery	1	27	Direction indicator switch (AZAW) see ref. 13	8
10	Stop lamp switch	12	28		
11	Windscreen wiper motor	13 - 14			
12	Distributor switch	7			
13	Direction indicator switch	8 - 9			

IDENTIFICATION OF WIRING HARNESES

Without mark AR.G	Front	AR.D P F.V.	Rear, R.H. Headlamp Jumper lead
	Rear, L.H.		

NOTE : Ref. = Identification N° of component on circuit diagram and wiring diagram.
 Position = Figure of vertical line numbered along lower edge on circuit diagram.